

bella™ 6qt Slim Air Fryer

Quick Start Guide

1. Insert the crisping tray.



2. Insert the assemble basket into the front of the air fryer.



3. Plug in the unit and press the power button to turn on the unit.

WARNING: Keep appliance at least 4 inches away from walls or other objects during operation.



4. Select one of the desired preset options. The preset time and temperature will appear and alternate on the screen.



5. To adjust the air fryer temperature, press the TIME/TEMP button until you see the temperature displayed then press (-) or (+) until you reach the desired temperature.



NOTE:
To toggle between Fahrenheit and Celsius, press and hold the TIME/TEMP button and the (+) button at the same time for 5 seconds.

6. To adjust the air fryer time, press the TIME/TEMP button until you see the time displayed then press (-) or (+) until you reach the desired time.



7. Press START/STOP to begin cooking.



WARNING: This air fryer should not be used to boil water. This air fryer should not be used to deep fry food. Please read the detailed instructions provided in the instruction manual.

bella™ Freidora de aire delgada de 6 cuartos de galón

Guía de inicio rápido

1. Inserte la bandeja para tostar.



2. Inserte la cesta de montaje en la parte delantera de la freidora de aire.



3. Enchufe el aparato y presione el botón de encendido.

ADVERTENCIA: Mantenga el aparato a una distancia mínima de 10 cm de paredes u otros objetos durante su funcionamiento.



4. Seleccione una de las opciones preestablecidas. El tiempo y la temperatura preestablecidos aparecerán en la pantalla, alternándose.



5. Para ajustar la temperatura de la freidora de aire, presione el botón TIME/TEMP hasta que aparezca la temperatura y, a continuación, presione (-) o (+) hasta alcanzar la temperatura deseada.



NOTA:
Para cambiar entre Fahrenheit y Celsius, mantenga presionados el botón TIME/TEMP y el botón (+) al mismo tiempo durante 5 segundos.

6. Para ajustar el tiempo de la freidora de aire, presione el botón TIME/TEMP hasta que aparezca el tiempo en pantalla y, a continuación, presione (-) o (+) hasta alcanzar el tiempo deseado.



7. Presione START/STOP para iniciar la cocción.



ADVERTENCIA: La freidora de aire no debe utilizarse para hervir agua ni para freír alimentos en aceite abundante. Consulte las instrucciones detalladas proporcionadas en el manual de instrucciones.

35233_35234_35235_35236_35237 RO