

ASSEMBLY INSTRUCTION

ITEM: 6081-75410-82 Upholstered Side Chair

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

PART LIST

No.	Drawing	Description	Size	Q'ty	No.	Drawing	Description	Q'ty
A		Allen Head Bolt	Ø5/16"x1-3/4"	1	1		Back Frame	1
В		Allen Head Bolt	Ø5/16"x3"	4	2		Seat Frame	1
С		Hexagon Nut	Ø5/16"	4	3		Front Leg	2
D		Lock Washer	Ø5/16"	9				
E		Flat Washer	Ø5/16"	9		Step 1		
F		Allen Key	4mm	1		Otop i		
G	5	Spanner Wrench	12mm	1				
Step	2	Step 3 F B (Bx4) D E (Ax1)				omplete		

Remark: DO NOT fully tighten all bolts until assembly is completed.