



- NOTE:
- | | | | |
|-------------|-----------------------|-----------|----------|
| (CONDITION) | (OL) OVEN LED | OG:ORANGE | BR:BROWN |
| DOOR:CLOSED | (FM) FAN MOTOR | YW:YELLOW | WH:WHITE |
| COOK:OFF | (TTM) TURNTABLE MOTOR | RD:RED | BK:BLACK |
| | (SM) STIRRER MOTOR | BL:BLUE | GY:GREY |
| | (CL) COOKTOP LED | GN:GREEN | PK:PINK |
| | (CM) CONVECTION MOTOR | | |
| | (DM) DAMPER MOTOR | | |