COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

701700
3Pc Coffee Table Set

REVISION 0 : 05/28/2026

COASTERFURNITURE.COM

ITEM: **701700**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME	15 MINUTES

PARTS IDENTIFICATION

A	COFFEE TABLE TOP		1PC
B	COFFEE TABLE LEG		4PCS
C	END TABLE TOP		2PCS
D	END TABLE LEG		8PCS


HARDWARE IDENTIFICATION

1	BOLT (M6 x 60MM - RBW)		24PCS
2	LOCK WASHER (M6 x 12MM - RBW)		24PCS
3	FLAT WASHER (M6 x 19MM - RBW)		24PCS
4	ALLEN WRENCH (M4 x 100MM - BLK)		1PC


ITEM: **701700**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



ITEM: **701700**


ASSEMBLY INSTRUCTIONS

STEP 3





STEP 4

COMPLETE



ITEM: **701700**





Note: Dimension tolerance ±5%