



Instruction Manual

Little CEO Learning Desk™



INTRODUCTION

Thank you for purchasing the **Little CEO Learning Desk™**.

With the **Little CEO Learning Desk™** kiddos can type, take a call and enjoy some tunes while keeping learning at an all-time high. Flip the page of the book, give the coffee a stir, move the mouse and open the webcam. Clock in and play the workday away!



1	Popping Plant	8	Magnifying Glass Button
2	Star Button	9	Mode Selector
3	Flipping Book	10	Stirring Cup
4	Dial Button	11	Telephone Base Button
5	Number Button	12	Rolling Pen
6	Alphabet Button	13	Mouse
7	Off/Low/High Volume Switch		

INCLUDED IN THE PACKAGE

- Little CEO Learning Desk™



Top of Desk



Removable Phone



4 Legs

- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.


WARNING

Adult assembly required.

ATTENTION

Ce jouet doit être assemblé par un adulte.

Unlock the Packaging Locks




- ① Turn the packaging locks 90 degrees counterclockwise.
- ② Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 3 new 1.5V AA (LR6) batteries following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

IMPORTANT : INFORMATIONS CONCERNANT LES PILES

- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -).
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.


PILES RECHARGEABLES :

- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.

ASSEMBLY INSTRUCTIONS

With the **Little CEO Learning Desk™** safety comes first. Adult assembly is required. For your child's safety, do not let them play with this toy until it is fully assembled.




1. Insert each table leg into the sockets on the bottom of the desk. Press firmly until the leg is secure. Check that all legs are stable before use.



2. To use the desk as a tabletop, gently pull the legs away from the desk. It can then be placed on any flat surface for the child to use.

PRODUCT FEATURES

1. **Off/Low/High Volume Switch**

To turn the unit **On**, slide the **Off/Low/High Volume Switch** to the **Low** volume  or **High** volume  position. You will hear fun sounds, a song and a phrase. To turn the unit **Off**, slide the **Off/Low/High Volume Switch** to the **Off**  position.



2. **Automatic Shut-Off**

To preserve battery life, the **Little CEO Learning Desk™** will automatically power down after approximately 16 seconds of inactivity. To turn the unit back on, press any button on the keyboard, the star button on the book, or the telephone base.

NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Dial Button

Press the **Dial Button** on the **Keyboard** to introduce phone and video calls. Fun sounds and songs will play to encourage the child to pretend to call. The light will flash with the sound.



2. Number Button

Press the **Number Button** on the **Keyboard** to introduce numbers. Fun sounds and songs will play to encourage the child to count. The light will flash with the sound.



3. Alphabet Button

Press the **Alphabet Button** on the **Keyboard** to introduce letters. Fun sounds and songs will play to encourage the child to learn and play. The light will flash with the sound.



4. Magnifying Glass Button

Press the **Magnifying Glass Button** on the **Keyboard** to play fun sounds and songs and encourage the child to explore the desk. The light will flash with the sound.



5. Star Button

Press the **Star Button** to hear fun sounds and songs. The light will flash with the sound.



6. Mode Selector

Slide the **Mode Selector** to choose between **Music Mode**, **Learn Mode** or **Explore Mode**. The light will flash with the sound.




7. Mouse

Slide the **Mouse** to hear fun sounds and a phrase. The light will flash with the sound.



8. Telephone Base

Press the Telephone Base to hear fun sounds and songs. The light will flash with the sound.



MELODIES

1. Bingo
2. Do You Know the Muffin Man?
3. Glow Worm
4. Head, Shoulders, Knees, and Toes
5. Hickory Dickory Dock
6. London Bridge
7. Cello Suite No.1 in G (Bach)

8. Oh Where, Oh Where Has My Little Dog Gone
9. One, Two, Buckle My Shoe
10. Skip to My Lou
11. Swan Lake Waltz (Tchaikovsky)
12. Good Morning, Merry Sunshine
13. Looby Loo
14. Sugarplum Fairy
15. Three Little Kittens

SONG LYRICS

Song 1

Work's all done, yay!
Now it's time to play,
Tap the keys, sing along, hip-hip hooray!

Song 2

Ring-ring, hi! When the screen shines bright.
Wave, bye-bye to soft twilight.

Song 3

Count one, two, three, come play with me,
Four, and five make numbers we see!

Song 4

ABCD, type with me,
Oh, and don't forget the E!

Song 5

Click and tap, look and play,
Discover magic every day!

Song 6

Open up, open up, what will you see?
A world full of colors and shapes for me!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE

If the problem persists, please contact our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5931
Product Name: Little CEO Learning Desk™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

