







# ASSEMBLY INSTRUCTION

Item#: 5615-75207-GRY Rectangle Dining Table w/2 18in leaves

**\*\* Please make sure you have all parts indicated below prior to assembly.  
This table is heavy and can best be assembled with the help of two or more persons.**

NO	HARDWARE LIST		Q'TY
A		Flat Washer 5/16*16mm	8
B		Lock Washer	20
C		Bolt 5/16*25mm	12
D		Allen Wrench	1
E		Bolt 5/16*19mm	8
F		Flat Washer 5/16*22mm	12





Diagram 1




Diagram 2

### Assembly Steps:

1. Put the stretchers onto pedestals, using bolts (E), lock washers (B), flat washers (A). Don't tighten them secure at the moment. (See Diagram 1).
2. Place table top upside down on a soft surface to prevent it from scratching.
3. Attach pedestals to top, using bolts (C), lock washers (B), flat washers (F), secure by turning with allen wrench (D) in a clockwise direction. (See Diagram 2)
4. Turn table upright.




Diagram 3

### Instruction for table leaves:

1. There are latches at the bottom of table top, turn off the latch as shown in diagram 2.
2. Pull out table top as the arrow direction shown in diagram 3.
3. Place table leaves between and push table tops together. Then turn on latches.
4. Take opposite actions to remove table leaves.

**Cleaning Instruction:** Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.