

Medium Back Executive Office Chair with Flip-up Arms

MODEL RTA-4902

ASSEMBLY INSTRUCTIONS

REV.2-MRY-A8567-1124



Thank you for purchasing our product!

Do a quick inventory of all the parts and hardware listed below.




For Support, assembly questions & Replacement Parts within the 48 *Contiguous* United States:

Please email us at: support@rtaproducts.com



Replacement Parts for International Customers & **AK-HI-PR** orders: RTA Products will replace the part free of charge, while the customer is responsible for shipping costs plus any International local taxes or duties.



HARDWARE LIST					
Part #	QTY	SIZE/Description	Item		
-	4	M6x20	mm 10 20 30 40 50 60		
J	12	M6x25	mm 10 20 30 40 50 60		
K	8	Hole caps			

INCLUDED TOOLS					
M5 Allen Wrench	M5				






RTA-4902



ASSEMBLY STEPS


STEP 1 FIRST: Attach F to C using pressure.



THEN: Insert E in the middle of C and cover it with H.


STEP₂


Assemble D to B with screws I making sure the tilt knob faces towards the FRONT.



STEP 3

Assemble the metal plate from the backrest A to the seat B with screws I, BUT LEAVE THEM LOOSE to allow flexibility for step 5.








ASSEMBLY STEPS

STEP 4


Join the seat with the base making sure E enters into D.



G-L


STEP 5

Assemble G-L and G-R to A and B in their respective sides with screws J, but screw loosely to allow flexibility on both sides.



STEP 6

FINALLY, Tighten all the screws and cover the holes with K.




RTA-4902



CHAIR'S FUNCTIONS

Pull Handle UP.

Pull Handle OUT to UNLOCK; Push Handle IN to LOCK.



Flip arms UP or DOWN.

Turn CLOCKWISE for less tension (-); COUTERCLOCKWISE for more tension (+).

With less tension, the tilting feels easier.

WARNINGS - Not paying attention to the following warnings could result in injuries.



Do not use the chair if the frame parts are damaged, or if any of the screws are loose or missing.





prevent the chair from tipping over.



Do not stand or use

the chair as ladder.

WEIGHT LIMIT DO NOT EXCEED





Do not leave babies or toddlers unattended while seated on the chair, always ensure adult supervision. Keep children from playing with the chair for their safety.

CARE AND MAINTENANCE


Clean with a soft cloth lightly damped in a solution of smooth soap and water.



Do not use solvents or abrasive materials.



Do not expose to direct sunlight or to extreme environmental conditions.



Inspect the chair throughly every 4 months and retighten the screws.



WARRANTY



LIMITED 2 YEAR WARRANTY

For details on the Warranty Policy, please visit online: www.technimobili.com