



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**504666
CHAIR**

ITEM : 504666

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A CHAIR




1PC

B BACK CUSHION



1PC

C LEG




4PCS

ITEM : 504666


ASSEMBLY INSTRUCTIONS




STEP 1





STEP 2



STEP 3




STEP 4



ITEM : 504666

ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$