Assembly Instruction for
KITCHEN ISLAND WITH CASTERS
DA-20440-8-KI

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST


No.	PART DESC	CODE.	Q'TY
A	Kitchen Island with Casters - Table Top		1
B	Kitchen Island with Casters - Base Frame	PDA-20440-8-KIBAS	1
C	Kitchen Island with Casters - Leg	PDA-20440-8-KILEG	4
D	Kitchen Island with Casters - PVC Liner for top Drawer	PDA-20440-8-KIPVC	3

⚠ Only tighten all bolts when all bolts aligned with bolt inserts.


HARDWARE LIST

No.	HARDWARE DESC	CODE.	Q'TY
1	Allen bolt (Ø1/4" * 1-3/8")	PDA-20440-CKIHW	2
2	Allen bolt (Ø5/16" * 2")		4
3	Spring washer (Ø5/16")		6
4	Flat washer (Ø5/16" * 3/4")		6
5	Allen key (Ø1/8")		1
6	Caster with Lock	PDA-20440-CKICAS	4
7	Screw (#4*3/4")		16
8	Towel Rail	PDA-20440-CKITWL	1

Step:1




Step:2




Assembly Instruction for
KITCHEN ISLAND WITH CASTERS
DA-20440-8-KI


Step:3




Step:4



Step:5




Completed




Assembly Instruction for
KITCHEN ISLAND WITH CASTERS
DA-20440-8-KI

Step:3



Step:4



Completed

