

MODEL : BBT 3175 A4 NIGHTSTAND

ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance.
Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.


NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.
Tool needed : Screwdriver (not provider).

PART LIST			
ITEM	DESCRIPTION	BOX	QTY
A	NIDHTSTAND	1	1 PC
B	LEG	1	4 PCS
C	HANDLE	1	2 PCS
D	HANDLE SCREW	1	4 PCS
E	FLAT WASHER	1	4 PCS
F	DRAWER	1	2 PCS


HARDWARE LIST (BOX : 1)		
ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 x 20mm 	8 PCS
2	M6 FLAT WASHER 	8 PCS
3	M6 SPRING WASHER 	8 PCS
4	M4 ALLEN KEY (BALL SHAPE) 	1 PC

STEP 1

Note:
Open the last of drawer and
take out all the parts.



STEP 2





ASSEMBLY INSTRUCTIONS

2 of 2

STEP 3

Note :
Hold the handle flat and
then tighten the screws



STEP 4

