

Roots Rack Kitchen Cart

CF3008





Congratulations! You have purchased a stylish piece of Crosley Furniture. We strived to provide fine furniture products, built with quality materials and hand finished details. Please carefully follow the assembly instructions to ensure your furniture is assembled correctly to provide long lasting enjoyment.

Should you experience any missing or damaged parts.do not return to the store,Please visit our website **www.Crosleyfurniture.com**,or contact us directly at 800-815-4796.

Care: Use a soft, clean cloth that will not scratch the surface when cleaning. The use of solvents is not necessary. Should you choose to use solvents, test in an inconspicuous area first to avoid damaging the finish. TO clean, simply use a soft, clean cloth lightly dampened with water.



HARDWARE LIST

0				0	
Long Bolt(M6*38mm)		Short Bolt(M6*28mm)		Flat Washer(M6mm)	
	4pcs	J	28pcs	K	16pcs
Spring Washer(M6mm)		Drawer handle		Handle Washer(M6mm)	
L	16pcs	M	2pcs	N	8pcs
Wood Dowel(M8mm)		Wrench(M17mm)		Allen Key(M4mm)	
0	12pcs	Р	1pc	Q	1pc

2 of 8













Limited Manufacturers Warranty

Crosley Furniture Products are warranted against defects in material and workmanship for a period of 90 days beginning from the date of sale. Should any parts be missing or defective, we will replace or repair the parts for a period of 90 days from the date of purchase.

Should you experience any missing or damaged parts, do not return to the store. Please contact us directly at 800-815-4796 from 9 AM to 5 PM (EST) Monday to Friday.

This warranty gives the purchaser specified legal rights in addition to any rights which may vary from state to state.

In accordance with the "Moss-Magnuson Warranty Act" of july 10, 1975, this is termed a "limited warranty" which in no way compromises Crosley Furniture's high standards of Quality and Workmanship.