


MEET YOUR ALEXA VOICE REMOTE ENHANCED



POWER UP YOUR ALEXA VOICE REMOTE ENHANCED

INSERT YOUR BATTERIES



Press and hold your thumb on the arrow to release the latch.



With one thumb pressing on the arrow, use your second thumb to slide open the cover. Insert included batteries.

TIPS AND TROUBLESHOOTING



Make sure you 1 press the arrow firmly to release the latch as you 2 slide the cover off.



If the new remote does not connect, remove and reinsert its batteries.

AAA

Always replace dead batteries with new 1.5V alkaline or 1.2V NiMH rechargeable AAA batteries.

SET UP YOUR ALEXA VOICE REMOTE ENHANCED

**IF YOU HAVE THE REMOTE
THAT CAME WITH YOUR
FIRE TV DEVICE, YOU'LL
NEED BOTH REMOTES
FOR SETUP**

NEW REMOTE

Insert batteries and press the Home  button one time.

ORIGINAL REMOTE

1. Press the Home  button, navigate to  on the menu bar, then select Controllers & Bluetooth Devices > Amazon Fire TV Remotes > Add New Remote.
2. Check if the new remote shows up in the list.
Tip: if the new remote does not show up in the list, long press Home  button for 10 secs. on the new remote.
3. Select the new remote from the list. You'll see an onscreen message when it has been successfully paired.

**YOU CAN NOW USE
YOUR NEW ALEXA VOICE
REMOTE ENHANCED**

**IF THIS IS A REPLACEMENT
REMOTE AND YOU DON'T
HAVE THE REMOTE THAT
CAME WITH YOUR
FIRE TV DEVICE**

RESTART YOUR DEVICE

Restart your Fire TV device by unplugging it and plugging it back in. Once the Home screen for Fire TV appears, wait 60 secs. until "Cannot detect your remote" is seen on the screen.

NEW REMOTE

Press Home  button once on the new remote. Remote should successfully pair with the Fire TV device and you should see a blue light flicker on the remote.

Tip: if it did not pair, press and hold the Home  button until the remote starts to flash amber (it may take 10 secs. or more).

A notification will appear on your screen indicating that your remote is successfully paired.

**YOU CAN NOW USE
YOUR NEW ALEXA VOICE
REMOTE ENHANCED**