

# ASSEMBLY INSTRUCTIONS

## ITEM #: D285-38 DINING BENCH




Thank you for purchasing this product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

**Before You Assemble:** Please read all instructions carefully before beginning assembly.






It is recommended that 2 people work together during assembly to prevent personal injury and to ensure that heavy or cumbersome parts are not damaged during the process.


**CAUTION:** For your safety, this product requires two people to lift.

### PARTS LIST:


NO	DESCRIPTION	SKETCH	QTY
A	SEAT FRAME		1PC
B	LEGS		2PCS
C	STRETCHER		1PC

### HARDWARE PACKAGE: EHF# D285-38-HDWR

NO	DESCRIPTION	SKETCH	SIZE	QTY
1	Allen key		4*59*23mm	1 pcs
2	Bolt		Ø5/16*40mm	6 pcs
3	Bolt		Ø5/16*30mm	2 pcs
4	Spring Washer		Ø5/16	8 pcs
5	Flat Washer		Ø5/16*19mm	8 pcs



**STEP 1** Place the seat frame (A) upside down on a soft surface such as a carpet to protect against scratches. Attach the legs (B) by using allen key (1), bolts (2) spring washer (4) and flat washer (5).



**STEP 2** Attach stretcher (C) to the legs(B) using allen key (1), bolt (3), spring washer (4) and flat washer (5)

