


ASSEMBLY INSTRUCTION




PARTS LIST










Warning:

Close parasol during windy conditions!

Keep umbrella fully closed during windy conditions. Store in provided Bag (C) if umbrella will not be used for prolonged periods.



Step 3
To adjust the umbrella angle, press the Tilt Button (C) and pull towards the desired direction. Release Tilt Button to lock angle in place.

