





6+





CONTENTS




Remove string with safety scissors (not included) before play.
Adult assistance recommended.

1. SET UP / RESET

Attach parts as shown before and after play.





2. APPLY LABELS




3. TO PLAY

A. Slam and break these parts off!





TIP: Break these parts off by hitting the spots as shown.

B. Crush the roof!



C. Destroy the cabin!




FIGURES NOT INCLUDED. SOLD SEPARATELY, SUBJECT TO AVAILABILITY.

3. TO PLAY (CONTD.)

D. Rock & rumble action!

Attach figure to the car top.

1




Rock side to side to rumble and fling open doors!

2




E. Launching action!


1 Remove the driver side door.



2 Place figure into the driver seat.



3 Press the license plate to launch!



WARNING: Do not aim at eyes or face.
Only use projectiles supplied with this
toy. Do not fire at point blank range.

©2026 Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted.

All WWE programming, talent names, images, likenesses, slogans, wrestling moves, trademarks, logos and copyrights are the exclusive property of WWE and its subsidiaries. All other trademarks, logos and copyrights are the property of their respective owners. © 2026 WWE. All Rights Reserved.



JMR51-0970G3
1102369819-Dom

