













**Please unscrew mechanism and L-bar hardware from cushion before assembly.**

**Por favor de destornillar todos los tornillos del cojín antes de ensamblar la silla.**

**MODEL : B8771/B8776**

(1)x1  Back Cushion	(2)x1  Seat Cushion	(3)x1 (L)x1 (R)  Left & Right-Arm
(4)x1  Gas Lift W/ Cover	(5)x1  Base	(6)x1  Mechanism
(7)x5  Caster		
(A)x4  M8*22 MECHANISM SCREW	(B)x4  M8*50 ARM SCREW	(C)x4  M8*25 L-BAR SCREW
(D)x4  ARM CAPS		



**Note: Please tighten all arm screws using allen key before step 6**

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

