

ASSEMBLY INSTRUCTIONS

MODEL #

FM7369AK-Q

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Allen Key (Included)



2 People





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday - Friday 8:30 AM - 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.





- 1		
- 1		
- 1		
- 1		
- 1		

Are you missing anything?

Double-check all parts, hardware and accessories listed are all acccounted for.



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.











ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Sufficient Space

assembly.

Make sure you have enough space to move around during the

Assembling near the area of the intended location is highly recommended.

















Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



HARDWARE




BOLT Ø5/16"*1-1/2" 8 pc.



SPRING WASHER Ø5/16"*Ø12*2MM 8 pc.




FLAT WASHER Ø5/16"*19*2MM 8 pc.



(5) Ø


ALLEN WRENCH 1 pc. SCREW 27 pcs.

ASSEMBLY INSTRUCTIONS




7/9

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS





Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag! To avoid damage to product please always LIFT the product when transporting of adjusting the placement.