

CBR1-1003 说明书 255x105MM

Barbasol®

Rechargeable Wet & Dry Shaver



USE AND CARE GUIDE
(For model: CBR1-1003)

Manufactured under exclusive license of Perio Inc. ©Barbasol

PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE

When using an electrical appliance, basic precautions should always be observed. Read all instructions before using this shaver.

DANGER

To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug it immediately.
2. Do not charge while bathing or in the shower.
3. Do not charge this unit near a tub, toilet or sink.

WARNING/IMPORTANT

1. Read the instruction manual thoroughly before using the device.
2. Use the shaver only for purposes described in this instruction book.
3. For the hygienic reason, the shaver should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the foil condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Foils and blades will wear over time and may require replacing.
8. This product is for household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
10. Keep your unit out of reach of children.
11. Do not charge the shaver where the temperature is below (32 F), or higher than (100 F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging USB cord only.
13. Dry the shaver completely before charging it.
14. Keep the USB charging cord away from water and handle with dry hands.
15. Do not pull, twist, or severely bend the cord.
16. Do not wrap the USB cord tightly around the appliance.
17. Do not take the housing apart.

PRODUCT INTRODUCTION



LCD SCREEN INDICATION



1. When full charged, Battery % will show 100. Also show you the remaining Battery % when use.
2. When the shaver is charging, the charging plug symbol lights up.
3. Press on/off switch 3 seconds to lock the shaver.
4. Re-press on/off switch 3 seconds to unlock the shaver.
5. After using 60mins, it will remind you to wash the shaver.

Barbasol®

6. When turn off the shaver, LCD display will show number and Battery % to indicate battery percentage remaining.



CHARGING

1. Use only the included USB cord supplied with the appliance.
2. Regular shaving will require 2 hours charging time for 60 minutes of run time. Usage time may decrease over time.
3. When you charge the shaver for the first time or after three months of disuse, let it charge continuously for 2 hours.
4. Do not overcharge, as this may damage the battery life.
5. Be sure to check that the "On/Off switch" is set to "Off" when charging.
6. Connect the charging cord on the charging connection of the shaver.
7. Connect the other end of the charging cord to a USB charge, current 5V 1A.

SHAVING

HOW TO USE

1. Switch on by pressing the on/off switch.
2. Hold the shaver at a right angle to your skin.
3. Apply gentle pressure as you move the shaver across your face, stretching the skin with your free hand. Move the shaver back and forth to achieve the desired result.
4. Applying excessive pressure will not result in a closer shave and may cause irritation or skin damage.

5. To use the beard trimmer, slide the trimmer handle up to open the trimmer place the trimmer at a right angle to your skin and move it downward to trim, sideburns.
6. If the shaver is no power, you can shave by connecting the shaver with USB cord to the charger current 5V 1A.

STORAGE

Always store this appliance and USB cord in a moisture-free area.

CLEANING

1. Turn off the shaver when cleaning.
2. Press the "Head released button" to release the "Head Cover". Remove any hair debris after each use using the brush provided.
3. Rinse the "Head Cover" only under running water.
4. Do not clean when it is charging.

DO NOT REMOVE THE BATTERY.

ENVIRONMENT PROTECTION

NOTE! The battery the appliance is equipped with contains substances, which may result in environmental pollution.

Do not dispose of the appliance. Please take all WEEE marked waste to your local recycling center for proper disposal.



2 Year Limited Warranty

Questions: call toll-free Barbasol Customer Service (844) 777-9601

Email Support: support@barbasoelectric.com

This product is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow operation and instruction guide will void this warranty.