





ITEM NAME/NOM D'ITEM: APERTO ACCENT CHAIR

ITEM # /NO. ITEM: 704122


PARTS LIST/LISTE DES PIÈCES

(1)	(3)	(5)
 x1	 x1	A.  M6x15mm x18
(2)	(4)	B.  M6x40mm x4
 x4	 x1	C.  M6x45mm x4
		D.  Ø16x1.0mm x10
		E.  M6 x6
		F.  4mm x1
		G.  connector x1


ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Do not FULLY TIGHTEN the screws or nuts for any step until all are in place


I




II



III




IV



Please use the attached adjustable footglides to level the chair on an uneven surface.

V



Attach connectors after setting preferred sectional configuration.

For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866) 798-6663

AI-V1-J007-241121