

BLUEY



Instruction Manual

MUSICAL MOMENTS PLAYER




BBC
STUDIOS

BLUEY (word mark and character logos) are trade marks of Ludo Studio Pty Limited and are used under licence. BLUEY logo © Ludo Studio Pty Limited 2018. Licensed by BBC Studios. BBC is a trade mark of the British Broadcasting Corporation and is used under licence. BBC logo © BBC 1996

INTRODUCTION

Put on headphones featuring Bluey's ears and hear sing-along songs, classical music, dance beats and soothing tunes just like on the show. Then, get up and boogie or play games with Bluey.



INCLUDED IN THE PACKAGE

- One **Musical Moments Player**
- One set of headphones
- One Quick Start Guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.


ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE :

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

Unlock the Packaging Locks:



- ① Turn the packaging lock counterclockwise several times.
- ② Pull out and discard the packaging lock.

GETTING STARTED

Exit Try-Me Mode

Plug the headphones into the Bluey Music Player to exit Try-Me Mode and the player will restart.

Before playing for the first time, please install 2 new AAA batteries. (The AAA batteries included in the unit are for demo purposes only and are not life long batteries).

INSTRUCTIONS

Note:

In order to protect your child's hearing, the volume level of the headphones is lower than the speaker.



WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.




ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.

Tenir les piles ou accumulateurs hors de portée des enfants.

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new 1.5V AAA (LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

IMPORTANT : INFORMATIONS CONCERNANT LES PILES

- Mettre en place les piles ou les accumulateurs en respectant les polarités + et –.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le –).
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.

PILES RECHARGEABLES

- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.

Note:

If the unit repeatedly powers down while playing or the light fades out, we suggest changing the batteries.

Product Features

1. ON/OFF BUTTON

Press the ON/OFF BUTTON to turn the unit ON. Press the ON/OFF BUTTON again to turn the unit OFF



2. VOLUME BUTTON

Press the VOLUME BUTTON to adjust the volume to low, medium or high.



3. FUNCTION BUTTONS

A) PLAY/PAUSE BUTTON

Play or pause the music by pressing the PLAY/PAUSE BUTTON .



B) PREVIOUS BUTTON & NEXT BUTTON

Press the PREVIOUS BUTTON & NEXT BUTTON to make a selection.


4. 4 MUSIC MODE BUTTONS

Press the different MUSIC MODE BUTTONS to hear different music styles and songs.



5. BLUEY TALK BUTTON **B**

Press the BLUEY TALK BUTTON to hear Bluey's fun phrases.



6. 2 ACTIVITY BUTTONS

Press the different ACTIVITY BUTTONS to play different games.



7. AUTOMATIC SHUT-OFF

To preserve battery life, the unit will automatically power-off after about 1 minute without input. The unit can be turned on again by pressing the ON/OFF Button.

ACTIVITIES

1. Songs



Explore different Bluey and Bingo songs from the show.

2. Fancy Music



Hear classical music from the show.

3. Dance Mode Music



Dance mode! Dance along to the music.

4. Relaxing Music



Listen to relaxing music for a moment of calm.

5. Bluey Talk Mode



Hear Bluey chat about her favorite things and gab about her day.

6. Musical Statues Game



Follow Bluey's instructions and freeze when the music stops.

7. Catch The Light Game



Press the left and right arrow buttons (previous and next buttons) to catch the lights as they appear on Bluey's headphones.

SONG LYRICS

1. FIVE LITTLE MEN IN A FLYING SAUCER

Five little men in a flying saucer
Flew round the world one day
They looked left and right
But they didn't like the sight
And then they flew away.

2. ONE MAN WENT TO MOW

One man went to mow
Went to mow a meadow
One man and his dog <yap>
Went to mow a meadow

Two men went to mow
Went to mow a meadow
Two men, one man and his dog <yap>
Went to mow a meadow

Three men went to mow
Went to mow a meadow
Three men, two men, one man and his dog <yap>
Went to mow a meadow.

3. POOR LITTLE BUG

Poor little bug on the wall
Jing Jing!
No one to love her at all
Jing Jing!
No one to tickle his toes
Jing Jing!
No one to blow his nose!
Jing Jing!

4. **BURGER DOG**

Burger Dog, B-Burger Dog.

He has pickles and he has cheese.

Burger Dog, B-Burger Dog.

Fluffy bun with some ses'me seeds.

Burger Dog, B-Burger Dog.

Yap yap yap yap yap yap yap!

Burger Dog, B-Burger Dog.

He was once a wiener dog, now he is a burger dog.

Burger Dog. B-Burger Dog.

5. **CHICKEN RAT**

Lay an egg

Lay an egg

Lay a chickenrat egg

For our breakfast

For our breakfast

Make a chickenrat egg

For our breakfast!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or visit our website **vtechkids.com** and fill out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5898
Product Name: Musical Moments Player
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES(B)/NMB(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

