




QUICK START GUIDE


SEE INSTRUCTION MANUAL FOR FULL INSTUCTIONS
AND IMPORTANT SAFETY INFORMATION.

PRODUCT COMPONENTS

- A. Power/Record Button
- B. Indicator Light
- C. Camera Lens

- **D.** Night Mode Bulbs **E.** Memory Card Port
- **F.** Charging Port





POWER ON/OFF

To Power On:

To turn on press and hold **POWER/RECORD** button for 4 seconds

To Power Off:

To turn off press and hold **POWER/RECORD** button for 4 seconds.


GETTING STARTED


STEP 1: To turn on press and hold **POWER/RECORD** button for 4 seconds. (*Figure A*) LED light will illuminate solid red. Cop Cam™ will start recording video when motion is detected. Ensure Cop Cam™ is oriented as shown so video is upright. (*Figure B*)


STEP 2: To switch to photo mode press and hold the **POWER**/ **RECORD** button for 2 seconds. LED light will illuminate solid green. To take a photo quickly press the **POWER/RECORD** button once.


STEP 3: To retrieve footage, remove memory card by pressing inward to release, then pull out of slot. (*Figure C*) Use included USB cable to connect Cop Cam™ to your Computer/Laptop. Access footage following prompts. (*Figure D*)

STEP 4: To charge Cop Cam[™], plug into computer/laptop. LED light will alternately flash red and green. (*Figure D*)









See instruction manual for additional camera use information & how to use wall mount/table stand & swivel clip.