



Warning:


Close parasol during windy conditions!

Keep umbrella fully closed during windy conditions.



<u>Step 3</u>
To adjust the umbrella angle, press the Tilt Button (C) and pull towards the desired direction. Release Tilt Button to lock angle in place.







Close parasol during windy conditions!

