

# Studio Display XDR

Before using Studio Display XDR, review the *Studio Display XDR Getting Started Guide* at [support.apple.com/guide/studio-display-xdr](https://support.apple.com/guide/studio-display-xdr). Retain documentation for future reference.

## Safety and Handling

See “Safety and Handling” in the *Studio Display XDR Getting Started Guide*.

## Safety Information

Failure to follow the safety instructions below could result in fire, electric shock, or other injuries, or damage to your Studio Display XDR or other property. Read all safety information below before using your Studio Display XDR.

## Handling

Set up your Studio Display XDR on a hard, stable work surface that allows for adequate air circulation under and around it. Never push objects into the ventilation openings. Your Studio Display XDR can be damaged if dropped, burned, punctured, or crushed, or if it comes in contact with liquids, oils, and lotions. Don't use a damaged Studio Display XDR, such as one with a cracked screen, as it may cause injury.

## Mounting Solutions

**Caution:** Keep hands and fingers away from the moving parts of the stand to avoid being pinched.

If you're using a Studio Display XDR with a built-in VESA mount adapter, read the *Studio Display XDR with VESA Mount Adapter Setup Guide* before you begin. Also read all the installation instructions and safety information that came with your VESA-compliant 100 x 100 mm mounting solution before attaching it to the VESA mount adapter.

**Important:** Agency Compliance Information and the serial number are marked on the bottom of the stand of your Studio Display XDR or the side of your built-in VESA mount adapter and may be obscured when using the VESA mount adapter with some mounting solutions.

## Power

Unplug the power cord (by pulling the plug, not the cord) and disconnect all cables if any of the following conditions exist:

- The power cord or plug becomes frayed or otherwise damaged.
- You spill something onto the display.
- Your Studio Display XDR is exposed to rain or excess moisture.
- Your Studio Display XDR has been dropped, or the case has been damaged.
- You suspect that your Studio Display XDR needs service or repair.
- You want to clean your Studio Display XDR.

The only way to turn off power completely is to unplug the power cord from the wall outlet. Make sure the power cord is within easy reach so that you can unplug your Studio Display XDR when you need to.

Your AC cord has a three-wire grounding plug (a plug that has a grounding pin). This plug fits only a grounded AC outlet. If you're unable to insert the plug into an outlet because the outlet isn't grounded, contact a licensed electrician to replace the outlet with a properly grounded one. Don't defeat the purpose of the grounding pin.

## Precautions

A display may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Follow the instructions by the manufacturer when using a stand or adapter for mounting the display.
- Always use furniture that can safely support your Studio Display XDR.
- Always ensure your Studio Display XDR is not overhanging the edge of supporting furniture.
- Always educate children about the dangers of climbing on furniture to reach your Studio Display XDR.
- Always route cords and cables connected to your Studio Display XDR so that they cannot be tripped over, pulled over, or grabbed.

- Always keep hands and fingers away from the moving parts of the stand to avoid being pinched.
- Never place your Studio Display XDR in an unstable location.
- Never place your Studio Display XDR on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the Studio Display XDR to a suitable support.
- Never place your Studio Display XDR on cloth or other materials that may be located between the Studio Display XDR and supporting furniture.
- Never place items on or around your Studio Display XDR that might tempt children to climb on top of the display or the furniture on which it's placed.

## Ventilation

Don't block the bottom or top ventilation opening of your Studio Display XDR. Don't place the Studio Display XDR where ventilation is restricted (for example, in a cabinet).

## Temperature

Don't expose the Studio Display XDR to excessive temperatures (ambient operating temperature should be 50° to 95° F or 10° to 35° C), moisture, or humidity. The Studio Display XDR is not recommended for outside use.

## Clean the Display

If your Studio Display XDR has nano-texture glass, clean it only using the included polishing cloth. If your Studio Display XDR has standard glass, clean it using the included polishing cloth or a dampened microfiber cloth. For infrequent cleaning of hard-to-remove substances on nano-texture glass or standard glass, you can use a 70 percent isopropyl alcohol (IPA) solution. Don't use furniture cleaner, glass cleaner, disinfecting wipes, hand sanitizer, or any other type of solvent.

## FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this product not authorized by Apple could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

Responsible party (contact for FCC matters only):

Apple Inc.  
One Apple Park Way, MS 911-AHW  
Cupertino, CA 95014  
USA  
[apple.com/contact](http://apple.com/contact)

**ISED Canada Compliance**  
CAN ICES-3 (B)/NMB-3(B)

#### ENERGY STAR® Compliance



As an ENERGY STAR partner, Apple has determined that standard configurations of this product meet the ENERGY STAR guidelines for energy efficiency. The ENERGY STAR program is a partnership with electronic equipment manufacturers to promote energy-efficient products. Reducing energy consumption of products saves money and helps conserve valuable resources. For more information about ENERGY STAR, visit [energystar.gov](http://energystar.gov).

This display is shipped with power management enabled, which allows the display to save power by decreasing luminance when used in a room with low ambient lighting. This automatic brightness control feature is enabled as a default setting in Displays settings. To adjust your display luminance manually, use the display brightness keys on your keyboard or the brightness adjustment slider in Displays settings.

#### Disposal and Recycling Information



The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For information about Apple's recycling program, recycling collection points, restricted substances, and other environmental initiatives, visit [apple.com/environment](http://apple.com/environment).

#### Software License Agreement

Use of Studio Display XDR constitutes acceptance of the Apple and third-party software license terms found at [apple.com/legal/sla](http://apple.com/legal/sla).

#### Apple One-Year Limited Warranty Summary

Apple warrants the included hardware product and accessories against defects in materials and workmanship for one year from the date of original retail purchase. Apple does not warrant against normal wear and tear, nor damage caused by accident or abuse. To obtain service, call Apple or visit an Apple Store or an Apple Authorized Service Provider—available service options are dependent on the country in which service is requested and may be restricted to the original country of sale. Call charges and international shipping charges may apply, depending on the location. Subject to the full terms and detailed information on obtaining service available at [apple.com/legal/warranty](http://apple.com/legal/warranty) and [support.apple.com](http://support.apple.com), if you submit a valid claim under this warranty, Apple will either repair, replace, or refund your hardware device at its own discretion. Warranty benefits are in addition to rights provided under local consumer laws. You may be required to furnish proof of purchase details when making a claim under this warranty.

© 2026 Apple Inc. All rights reserved. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Studio Display XDR is a trademark of Apple Inc. Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and regions. ENERGY STAR and the ENERGY STAR mark are registered trademarks owned by the U.S. Environmental Protection Agency.  
Printed in XXXX. 034-07320-A