




**36" ELECTRIC BUILT-IN COOKTOP**

**MODELS:**

MEC8836HS00 (Stainless)

# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10437092	Switch, Infinite (Left Front & Right Rear)	14	3400093	Screw
	W11206696	Instructions, Installation				15	7101P426-60	Screw
	W11245478	Instructions, Undercounter Installation		W10843843	Switch, Infinite (Left Rear)	16	7101P309-60	Screw
	W11161590	Guide, Use & Care		W10578768	Switch, Infinite (Center Rear)	17	W11175341	Rail, Short
	W11238364	Diagram, Wiring		W10437094	Switch, Infinite (Right Front)	18	W11175343	Rail, Horizontal
2		Cooktop	11	W10248259	Element, Bridge (Left Front & Left Rear)	19	W11192139	Grill/Griddle
	W11269300	Stainless				20	W10471482	Switch, TOD High Limit
3		Trim, Stainless (Not Serviced)		8273994	Element (1200W) (Center Rear)			FOLLOWING PARTS NOT ILLUSTRATED
4	W10311897	Shield, Outer		W10342780	Element (1300W) (Right Front)	W11110559		Harness, Main
5	W10225448	Spring, Element		W10711900	Element (3000W) (Right Rear)	3192439		Seal, Limiter
6	W11215839	Plate, Switch				7101P426-60		Screw (For Main Harness)
7		Grommet				8286642		Tape, Foam
	W10293874	Black				W11183280		Insulation, Cooktop (Knob)
8		Box, Burner (Not Serviced)	12	3183956	Seal, Switch Cover			
9		Knob, Control	13	4455917	Bracket, Cooktop Mounting			
	W10859808	Stainless						

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
W10355016		Cleaner, Stainless Steel
WA906B		Scraper, Cooktop
W10355051		Cleaner, Cooktop
31605		Kit, Cooktop Care