Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

COUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.


3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
Α	BODY	1	1 PC	
В	HANDLE	1	2 PCS	
С	HANDLE SCREW	1	4 PCS	
D	FLAT WASHER	1	4 PCS	
E	DRAWER	1	2 PCS	

HARDWARE LIST (BOX : -)			
ITEM	DESCRIPTION	QTY	
-	-	-	



STEP 3

