










Thank you for purchasing the **MODWAY FULL/QUEEN BED** !

Before you start, here is some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the bed, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximately assembly time: 45 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe and environmentally friendly way.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that has been provided.
6. Please keep all fitting out of reach of children.



Hardware:

A		Short Bolt M6x20mm	x28
B		Medium Bolt M6x35mm	x4
C		Long Bolt M6x50mm	x4
D		Nut M6	x8
E		Arc Washer	x4
F		Rubber Insert	x16
G		Allen Wrench	x1
H		Open Wrench	x1

Component:



1	Headboard	x1	2	Footboard	x1
3	Side Rail	x2	4	Double Slat	x4
5	Single Slat	x8	6	Low Post	x2
7	Center Rail	x1	8	Support Leg	x4


STEP 1:

Take off the protective plastic caps from the bottom of **Headboard (1)**

Insert **Low Post (6)** into **Headboard (1)** as shown.

Attach by using **Arc Washer (E)** and **Short Bolt (A)** from the holes on the back of **Low Post (6)** and **Headboard (1)**.

Use **Allen Wrench (G)** to tighten **Short Bolts (A)** clockwise until secure.



Ax4	Ex4	Gx1


Hardware & Tool required

STEP 2:

Insert 4 pieces of **Medium Bolt (B)** into the 4 holes on **Center Rail (7)** by using **Allen Wrench (G)** to connect it with **Support Legs (8)** as shown.

Please pay attention to the holes' direction.

Tighten **Medium Bolts (B)** with 1 piece of **Nut (D)** by using **Allen Wrench (G)** and **Open Wrench (H)** until secure.



Bx4	Dx4	Gx1	Hx1

Hardware & Tool required

STEP 3:


Take out all **Double Slats (4)** and place them as shown.

Attach **Double Slats (4)** to the **Center Rail (7)** by using **Bolts (C)** and **Nuts (D)**.

Please pay attention to the holes' direction on the **Double Slats(4)**

Tighten **Long Bolts (C)** and **Nuts (D)** with **Allen Wrench (G)** and **Open Wrench (H)**.

Do not fully tighten **Long Bolts (C)** at this step.



STEP 4:


Take out **Single Slats (5)** and place them as shown.

Insert one end of **Single Slats (5)** into **Rubber Insert (F)** then insert them into the corresponding holes on 1 piece of **Side Rail (3)** as shown.

Attach assembled **Double Slats (4)** to the **Side Rail (3)** by using **Short Bolts (A)**.

Tighten **Short Bolts (A)** with **Allen Wrench (G)**. Do not fully tighten **Short Bolts (A)** at this step.

Repeat above for the other **Side Rail (3)**.



STEP 5:

Insert **Bolts (A)** into the bottom holes on the assembled **Headboard (1&6) & Footboard (2)** by hand.


Leaving 0.3~0.4inch space of the thread of **Bolts (A)** as shown.

Insert the notch of assembled **Side Rails (3&4&5)** into the space left on the **Bolts (A)**.

Screw **Bolts (A)** into the top holes on the assembled **Headboard (1&6) & Footboard (2)** as shown.

Fixation **Bolts (A)** with **Allen Wrench (G)** after all assembled.

Please fully tighten all **Bolts(A)(C)** at this step.



AX8	Gx1

Assembly is completed. Your bed is ready to be enjoyed now!

Hardware & Tool required

STEP 6:

