

## Quick Start Guide

**PowerXL™**  
products that excel

## AIR FRYER GRILL

See owner's manual for complete instructions and important safety information before using this product.

**IMPORTANT:** Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).

### STEP 1



#### Insert Drip Tray

Insert the Drip Tray **below** the bottom heating elements (at the very bottom of the Unit).

### STEP 2



#### Insert Crisper Tray

Place food on a Crisper Tray\* and slide the Tray into one of the shelves on the inside of the Unit. Use the markings on the door of the Unit to choose the best shelf to use for your recipe.

*\* The Pizza Rack and Grill Plate also slide into the shelves. The Baking Pan should be placed on top of the Pizza Rack when the Baking Pan is used.*

### STEP 3



#### Set Cooking Settings

Use the Function Knob to select the Air Fry cooking preset. Use the Temperature/ Darkness Control Knob to set the cooking temperature. Use the Time Control Knob to set the cooking time.

### STEP 4



#### Remove Crisper Tray

When the cooking cycle is complete, use oven mitts or potholders to remove the Crisper Tray by sliding it out of the Unit.

## Quick Start Guide

**PowerXL™**  
products that excel

## AIR FRYER GRILL

See owner's manual for complete instructions and important safety information before using this product.

**IMPORTANT:** Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).

### STEP 1



#### Insert Drip Tray

Insert the Drip Tray below the bottom heating elements (at the very bottom of the Unit).

### STEP 2



#### Insert Grill Plate

Place food on the Grill Plate and slide the Grill Plate into one of the shelves on the inside of the Unit. Use the markings on the door of the Unit to choose the best shelf to use for your recipe.

### STEP 3



#### Set Cooking Settings

Use the Function Knob to select the Grill or Air Fry/Grill cooking preset. Use the Temperature/Darkness Control Knob to set the cooking temperature. Use the Time Control Knob to set the cooking time.

### STEP 4



#### Remove Grill Plate

When the cooking cycle is complete, use oven mitts or potholders to remove the Grill Plate by sliding it out of the Unit.